



MADE IN GERMANY

Wassermann is a medium-sized, owner-operated company with head office in Hamburg. We design and produce high-quality technical devices in Germany. Our main users are dental laboratories, dental clinics and various industrial areas worldwide.

Why a Wassermann product?

Wassermann products are manufactured from high-quality materials and the proportion of plastics used is intentionally kept as low as possible. Our devices are known for their suitability for daily use, functionality and longevity. As a result, the users place high levels of trust in the Wassermann brand. We feel it is our duty to support our customers on a daily basis when it comes to safety, service and productivity. Technological perfection, optimum quality and especially sustainability are the benchmarks we set. Thanks to the combination of these values, the family-owned company, since its establishment in 1927, has gained worldwide recognition as a manufacturer of high-quality products.



Further information are available on our website at www.wassermann.hamburg

Your Dental Dealer _____

APR-1



Ejection Press



Wassermann Dental-Maschinen GmbH
Rudorffweg 15-17 · 21031 Hamburg · Germany
Phone: +49 (0)40 730 926-0 · Fax: +49 (0)40 730 37 24
info@wassermann-dental.com · www.wassermann.hamburg

Ejection Press APR-1

With the **APR-1** deflashing of cast rings works: Using only little power by just pushing down the lever, almost dust-free and entirely safe. Due to the even and centered pressure from above the castings come out undamaged and hence are fit for long term use.



Individual choice of lever position,
vertical or angled

Readily available pressure pieces
attached to the housing

The APR-1 can be screwed to desk,
wall mount available as an option

Exact grip of cast rings by
matching cast iron cube

Major Features

- **Included in delivery:**
 - Cube for cast rings / cast flasks (DeguDent / Heraeus Kulzer)
 - Pressure piece Ø 26
 - Pressure piece Ø 43
 - Pressure piece Ø 60
 - Pressure piece Ø 75

| Accessories | Item no. |
|-------------|----------|
| Wall mount | 128100 |

| APR-1 | Item no. 128999 |
|--------------------|--------------------|
| W x H x D | 160 x 380 x 160 mm |
| Height with handle | 670 mm |
| Weight | 13.8 kg |
| Cube size | 97 x 97 x 97 mm |