




SG-10
modular filter system
for different applications



SG-10 base with module
activated carbon filter



SG-10 Basis
with module filter add-on



To retrofit the SG-10 basic
version with an activated carbon
filter the following item
numbers are necessary:

140410
Module filter add-on
(without filter)

610074
Micro fine dust filterbag
(yellow) tall, dust class M

140424
Module activated carbon filter:
Activated carbon filter (AKM
6-ply), filter cassette (dust class F),
filter housing (no fig.), filter frame

MADE IN GERMANY

Wassermann is a medium-sized, owner-operated company with head office in Hamburg. We design and produce high-quality technical devices in Germany. Our main users are dental laboratories, dental clinics and various industrial areas worldwide.

Why a Wassermann product?

Wassermann products are manufactured from high-quality materials and the proportion of plastics used is intentionally kept as low as possible. Our devices are known for their suitability for daily use, functionality and longevity. As a result, the users place high levels of trust in the Wassermann brand. We feel it is our duty to support our customers on a daily basis when it comes to safety, service and productivity. Technological perfection, optimum quality and especially sustainability are the benchmarks we set. Thanks to the combination of these values, the family-owned company, since its establishment in 1927, has gained worldwide recognition as a manufacturer of high-quality products.



Further information are available on our website at
www.wassermann.hamburg



/WassermannDentalmaschinen

Your Dental Dealer _____

SG-10




Suction Unit



Wassermann Dental-Maschinen GmbH
Rudorffweg 15-17 · 21031 Hamburg · Germany
Phone: +49 (0)40 730 926-20/ -24 · Fax: +49 (0)40 730 37 24
export@wassermann-dental.com · www.wassermann.hamburg
www.facebook.com/WassermannDentalmaschinen

Suction Unit SG-10

Safety and health in the workplace due to the innovative filter concept, wide range of filters available: From the activated carbon filter to the large volume plaster pre-filter



Filterbag large, available for micro fine dust or for plaster

Module filter add-on

Filter frame

Activated carbon filter


Filter cassette, dust class F

The SG-10 is a multi-function allround unit for many purposes from polishing motors to blasting units. As all Wassermann suction units which works with the low-pressure principle, it sucks up the maximum amount of air at a very low air speed. The advantage: Relaxed and quiet working conditions. A further advantage is the high suction volume, where the hands do not become cold even in continuous operation. The fan motor is a squirrel-cage motor almost free from wear and maintenance-free.

PVC-hose Ø 75 mm, various lengths available, see flyer "Accessories for suction technology".

The SG-10 suction unit base, comes as standard with filterbag small, available for micro fine dust or for plaster (for activated carbon mode this filter bag has to be removed and the activated carbon filter module is inserted into the SG-10 base instead)

As standard the power control is infinitely variable using the control element on the housing, an external control element can be retrofitted



Major Features

- Notably flexible and powerful universal suction unit
- Suitable for continuous operation, high-quality finish
- Filter saturation display
- Easy-to-replace filter system
- Recommended version for our Wassermann fine blasting units
- **Included in delivery:**
Supply line with switchable shock proof plug
Speed regulator, fitted on the housing
Micro fine dust filterbag (yellow) small, dust class M*

Accessories	Item no.
Spare micro fine dust filterbag (yellow) small, dust class M, 1 set = 4 pieces	611010*
Spare filterbag for plaster (white) small, class 1 / class 2, 1 set = 4 pieces	611018*
Spare micro fine dust filterbag (yellow) large, dust class M	610074**
Spare filterbag for plaster (white) large, class 1 / class 2	610073**
Spare activated carbon filter, cpl., AKM 6-ply	140436**
Spare filter cassette, cpl., dust class F	140435**
External speed regulator for fan control, can be retrofitted	140408

*SG-10 basic version, **SG-10 activated carbon version

For further accessories (e.g. PVC-hoses) please see flyer "Accessories Suction Technology".

SG-10 basic version SG-10 activated carbon version	Item no. 140988 Item no. 140987
Voltage	220–240 V / 50/60 Hz
Power consumption	0.75 A
Output	110 W
W x H x D SG-10 basic version	348 (without plug) x 423 x 270 mm
W x H x D SG-10 activated carbon version	348 (without plug) x 672 x 270 mm
Weight depends on version	8.2 kg
Sound level	≤ 70 dB (A)
Suction capacity	600 m ³ /h (free-blowing)
Extractor nozzle	Ø 75 mm exterior