

● **EJECTION PRESS****APR-1**

Easy extraction? No problem!

**Technical information**

Safe and simple to use: With the APR-1, flasks almost release themselves. Flasks are freed virtually dust-free and completely safely using very little force and just by operating a lever. The even, central pressure from above ensures the castings come out undamaged and fit for long-term use. The user can change the lever position so it is more comfortable to operate. Very practical: The pads to suit different flask sizes fit into the housing so they cannot go missing. In a word: You can do without lots of things, but not the APR-1.

- robust ejection press for safe and clean results
- easy to operate - very little force required
- clean extraction thanks to even, centred pressure
- selectable lever position - vertical or at an angle
- easily accessible pads for different flask sizes set into housing
- precision die grips flask cleanly
- unit can be screwed to desk - wall mount available as an option

● Technical data and accessories

APR-1	Item no.: 128999
W x H/H incl. handle x D	160 x 380 /670 x 160 mm
Weight	13.8 kg
H with grip	670 mm
Cube size	97 x 97 x 97 mm

Incl. in delivery	Item no.:
Cube for cast rings / cast flasks (DeguDent / Heraeus Kulzer)	128006
Pressure piece Ø 26	128020
Pressure piece Ø 43	128011
Pressure piece Ø 60	128010
Pressure piece Ø 75	128009
Accessories	Item no.:
Wall mount	128100

Technical changes reserved



Major features at a glance

- indispensable ejection press for clean and safe results
- very little force required
- pads for different flask sizes set into housing
- table or wall mounting

www.wassermann-dental.com