

● SUCTION UNIT SG-10

Powerful universal suction



Technical information

Flexible, compact and really powerful: The SG-10 is a multi-function allround unit for many purposes from polishing motors to blasting units. As all Wassermann suction units which works with the low-pressure principle, it sucks up the maximum amount of air at a very low air speed. The advantage: relaxed and quiet working conditions. A further advantage is the high suction volume, where the hands do not become cold even in continuous operation. The fan motor is a squirrel-cage motor nearly free from wear and maintenance-free.

- power control is infinitely variable using the control element
- modular filter system for different uses
- innovative filter concept
- other filters available: from the activated carbon filter to the high-volume plaster pre-filter
- recommended version for the Cemat-NT and Puna blasting units
- high-quality finish
- filter saturation display

● Technical data and accessories

SG-10 SG-10 activated carbon version	Item no.: 140988 Item no.: 140987*
Voltage*	220–240 V / 50/60 Hz
Power consumption	0.75 A
Output	110 W
W x H x D	348 (without plug) x 423 x 270 mm 348 (without plug) x 672 x 270 mm*
Weight	8.2 kg depends on version
Sound level	< 70 dB (A)
Suction capacity	600 m ³ /h (free-blowing) 270 m ³ /h (operating state)
Extractor nozzle	Ø 75 mm exterior

Incl. in delivery	Item no.:
Supply line with switchable shock proof plug	140022
Micro fine dust filterbag (yellow) small, dust class M (only 140988)	—
Speed regulator, fitted	140440
Micro fine dust filterbag (yellow) tall, dust class M*	610074
Filter extension module (without filter)*	140410
Module activated carbon filter (with filter)*	140424
Accessories	Item no.:
Spare micro fine dust filterbag (yellow) small, dust class M, 1 set = 4 pieces	611010
Spare filterbag for plaster (white) small, class 1 / class 2, 1 set = 4 pieces	611018
Spare filter cassette, cpl.	140435
Spare filterbag for plaster (white) tall, class 1 / class 2*	610073
Spare micro fine dust filterbag (yellow) tall, dust class M*	610074
Spare activated carbon filter, cpl.*	140436

* Other voltages on request

Technical changes reserved



Major features at a glance

- universal suction unit works with the low pressure principle
- power control is infinitely variable using the control element
- suitable for continuous operation
- modular system
- nearly free from wear and maintenance-free
- wide range of special accessories available
- filter saturation display
- easy-to-replace filter system
- high-quality finish

www.wassermann-dental.com