

**MADE IN GERMANY**

Wassermann is a medium-sized, owner-operated company with head office in Hamburg. We design and produce high-quality technical devices in Germany. Our main users are dental laboratories, dental clinics and various industrial areas worldwide.

**Why a Wassermann product?**

Wassermann products are manufactured from high-quality materials and the proportion of plastics used is intentionally kept as low as possible. Our devices are known for their suitability for daily use, functionality and longevity. As a result, the users place high levels of trust in the Wassermann brand. We feel it is our duty to support our customers on a daily basis when it comes to safety, service and productivity. Technological perfection, optimum quality and especially sustainability are the benchmarks we set. Thanks to the combination of these values, the family-owned company, since its establishment in 1927, has gained worldwide recognition as a manufacturer of high-quality products.



DEG-2, rotatable door with quick fastener



DEG-2 with polymerisation trough, available as accessory



DEG-1



DEG-1, rotatable door with quick fastener

**DEG-2 and DEG-1**



**Compactors**



Further information are available on our website at [www.wassermann.hamburg](http://www.wassermann.hamburg)

Your Dental Dealer \_\_\_\_\_



Wassermann Dental-Maschinen GmbH  
 Rudorffweg 15-17 · 21031 Hamburg · Germany  
 Phone: +49 (0)40 730 926-0 · Fax: +49 (0)40 730 37 24  
[info@wassermann-dental.com](mailto:info@wassermann-dental.com) · [www.wassermann.hamburg](http://www.wassermann.hamburg)

# Compactors DEG-2 & DEG-1

The DEG-2 and DEG-1 high-power compactors for hardening embedding and silicone duplicating materials compress the residual air completely so they create a dense, homogeneous product. Depending on the inlet pressure, up to 6.0 bar can be achieved and afterwards be reduced as desired. Both devices are designed to take several muffles at the same time.



DEG-2 with thermal fuse to protect the heating

Pressure chamber with quick fastener

Automatic timer up to 60 minutes

Pressure switch: The pressure-embedding process can be interrupted at any time

DEG-2 with integrated heater with two settings (37°C/55°C)

## Major Features

- For a dense, homogeneous structure and smooth rough castings
- Integrated stainless steel plates, designed for multiple muffles
- Pressure control valve for maximum safety
- Non-return valve for steady operating pressure
- Automatic venting: After the set time has expired, the pressure chamber will vent automatically
- **Incl. in delivery:**  
Compressed air hose, 2 m  
Supply line

### Accessories

Accessories	Item no.
Compressed air hose per meter	320026
Polymerisation trough DEG-2	180053

### DEG-2 DEG-1

	Item no. 180996 Item no. 180999
Voltage	220-240 V / 50/60 Hz
Power consumption DEG-2	4.2 A
Power consumption DEG-1	0.1 A
Output DEG-2	1000 W
Output DEG-1	20 W
W x H x D DEG-2	345 x 285 x 450 mm
W x H x D DEG-1	300 x 230 x 380 mm
Weight DEG-2	19.7 kg
Weight DEG-1	13.2 kg
Sound level	≤ 70 dB (A)
Compressed air connection	min. 3.5 bar
Operating pressure	max. 6 bar
Pressure chamber H x D DEG-2	130 x 285 mm
Pressure chamber H x D DEG-1	130 x 250 mm