

● FINE BLASTING UNIT

GOBI-2/ -3 /-4

Surface processing with growth potential



Gobi-4

Technical information

This unit grows to meet your requirements: The Gobi-2 enables you to work not only very efficiently and quick but is also extremely flexible. Due to its modular structure the basic unit can be extended by 1 or 2 blasting material containers, up to 4 chambers thus making it possible to use all common blasting materials and grain sizes. In addition optimum working conditions are guaranteed by the quick, foot-controlled start/stop function. Next to its ergonomic handpieces the Gobi also satisfies of special particularly durable hoses and its low consumption of blasting materials.

- reliable and reasonably priced fine blasting units with 2 to 4 chambers
- quick foot-controlled start/stop function
- precise working pressure of 1–6 bar with pressure gauge control
- optimum illumination, protected fluorescent lamp
- special, particularly durable hoses
- convenient colour coding system
- comfortably to handle with ergonomically shaped handpieces
- rapid ventilation of the blasting material containers for rapid re-filling and changing of blasting material

● Technical data and accessories

Gobi 2	Item no.: 190896
Voltage*	220–240 V / 50/60 Hz
Power consumption	0.2 A
Female connector power consumption max.	8 A
Output	50 W
W x H x D	430 x 350 x 530 mm
Weight	17.5 kg
Sound level	≤ 70 dB (A)
Tank capacity	800 cm ³ = 1.2 kg
Compressed air connection	3–6 bar
Working pressure	1–6 bar
Extractor nozzle	75 mm

We recommend the use of Wassermann blasting materials and our suction unit SG-10 / SG-20.

Incl. in delivery	Item no.:
PVC hose Ø 8x6 textile (blue) 2 m	320026
Supply line	592012
Gobi-2 incl. 2 fine blasting nozzles, 0.8 (blue), 1.2 (red)	190896
Gobi-3 incl. 3 fine blasting nozzles, 0.8 (blue), 1.2 (red) and optionally additional tank, left with fine blasting nozzle 0.6 (yellow) or 0.8 (green)	190896 + item no. additional tank
Gobi-4 incl. 4 fine blasting nozzles, 0.8 (blue), 1.2 (red) and additional tank, left with fine blasting nozzle 0.6 (yellow) and additional tank, right with fine blasting nozzle 0.8 (green)	190896 + 2 x item no. additional tank

Accessories	Item no.:
PVC hose Ø 8x6 textile (blue) per meter	320026
Additional tank, left with fine blasting nozzle 0.6 mm (yellow)	190800
Additional tank, right with fine blasting nozzle 0.8 mm (green)	190802
Spare fine blasting nozzle 0.6 mm	190550
Spare fine blasting nozzle 0.8 mm	190551
Spare fine blasting nozzle 1.2 mm	190552

*Other voltages on request

Technical changes reserved



Gobi-2



Gobi-3



Gobi-4



Additional tank

Major features at a glance

- fine blasting units of modular structure extendable to up to 4 chambers
- optimum workspace illumination, hygienic changeable sleeves
- possibility to connect to suction unit
- long durability, high flexibility
- quick start-stop function, low consumption of blasting material
- specially coated protection screen for ideal visibility

www.wassermann-dental.com