

developed for more flexibility

efficient & powerful

Our new **Steam Box** is a compact work cabin for cleaning workpieces by means of steam.

OUR PROVEN RECIPE FOR SUCCESS:

We combine technology, experience, competence and team spirit.

Steam-Box

Steam cabine with integrated suction system





Always available for you

Would you like to request a quote or place an order? Or do you have questions about your order, delivery or warranty?

We look forward to your call and will be happy to help you.

Service Hotline +49 (0)40 730 926-0





www.wassermann.hamburg



fb.com/WassermannDentalmaschinen

SCAN ME





Steam-Box

Steam cabine with integrated suction system





QUALITY MADE IN GERMANY SINCE 1927

New now! Steam cabin with suction system and intergrated foot pedal and hand sensor control. Perfect protection for first-class results: Our new steam box combines maximum safety with maximum comfort.



The most functions and features at a glance:

- Constructed for long life
- With integrated dust particle filter
- Foot pedal and hand sensor control
- Low-maintenance and easy to clean
- Compact work cabin for cleaning workpieces by means of steam
- Large working area (W= 285 mm, H= 235 mm)
- Fast steam extraction by powerful fan with overrun control
- Automatic fan operation selectable via foot pedal or hand sensor control
- Collecting tray can be emptied by means of side ball valve
- With practical handles:

The work cabin can be guickly dismantled for cleaning the collection tray

■ LED Lights for a comfortable and safe light environment

Technical Data:

Output: $W \times H \times D$ (max.): 421 x 476 x 549 mm Weight: Wx Hx D (housing): 393 x 476 x 515 mm Protection class: IP 44 Power consumption: 0,8 A

26,5 kg

Support Service:

Wassermann Dental-Maschinen GmbH Rudorffweg 15 - 17 21031 Hamburg

Tel: +49 (0)40 730 926-0 www.wassermann-dental.com sales@wassermann-dental.com