

“Engineered for Maximum Flexibility

Powerful • Flexible • Durable

Our Best Seller:

Wassermann's top-selling trimmer - now even stronger, more efficient, and more refined.

OUR TIME-TESTED BEST SELLER:

We combine technology, experience, expertise, and team spirit.

Dry Trimmer HSS-TR



Always here for

Do you want to request a quote, order products, or have questions about your order, delivery, or warranty?

We look forward to your call and are happy to assist you.

Info-Hotline

+49 (0)40 730 926-0



www.wassermann.hamburg



fb.com/WassermannDentalmaschinen

SCAN ME ➔



Dry Trimmer HSS-TR

NEW Powerful with a
New Look

QUALITY MADE IN GERMANY SINCE 1927

Its unique central connection for the suction unit ensures optimal suction performance. The powerful, high-torque, yet energy-efficient motor achieves maximum grinding speeds.



Key Features at a Glance:

- Versatile: Compatible with various Wassermann grinding discs
- High-torque, maintenance-free motor (up to 3,000 RPM)
- Stable and solid construction from stainless steel and premium aluminum
- Central connection for suction unit
- Powerful disc and interior suction
- Safe and easy to open, with no unnecessary seals
- Large working area of 10.5 x 13.5 cm
- KMS grinding devices also available in Swiss and EOS versions

HSS-TR
Item No. 163990

Technical Specifications

Power: 1,000 W
Current: 4.6 A

Weight, without Grinding Disc: 19.8 kg
Dimensions (W x H x D): 330 x 335 x 410 mm

Speed: 3,000 RPM
Voltage: 220-240 V

Info & Consultation:

Wassermann Dental-Maschinen GmbH
Rudorffweg 15 - 17
21031 Hamburg, Germany

Tel: +49 (0)40 730 926-0
Fax: +49 (0)40 730 37 24
www.wassermann-dental.com
sales@wassermann-dental.com