

“developed
for more
flexibility

• **efficient & powerful**

Our new **SG-Economy** can be used in many ways, depending on your personal requirements.

Our proven recipe for success:

We combine technology, experience, competence and team spirit.



Always available for you

Would you like to request a quote or place an order? Or do you have questions about your order, delivery or warranty?

We look forward to your call and will be happy to help you.



www.wassermann.hamburg



fb.com/WassermannDentalmaschinen

**Suction Unit
SG-Economy**



Info-Hotline

+49 (0)40 730 926-0



SCAN ME



WASSERMANN
Hamburg · Germany

Suction Unit SG-ECONOMY



Versatile in Use: SG-Economy ...

This efficient suction unit is used to extract dental dust at the workplace and to extract polishing dust and fine blasting units. It can be used in many ways, depending on your personal requirements



The most functions and features at a glance:

- Suction unit with highly efficient motor and convenient automatic start and stop system (auto/ manual mode selectable)
- Clearly structured user interface for quick and easy handling
- With filter status warning and automatic cleaning function of the cartridge filter
- Adjustable motor power regulation (25%, 50%, 75%, 100%)
- Expandable to two places (adapter available as an accessory)
- Almost noiseless operation, suitable for continuous operation
- High safety standard: With a practical automatic switch-on as well as an integrated run-on
- Safety and health in the workplace due to the 3 stage filter system including main filter / cartridge filter of class M according to EN 60335-2-69 (washable), filterbag box (optionally bagless or bagged: 7 lor 10 l) and HEPA exhaust filter

Notizen:

Technical Data

Motor: 900 W
Depression: 1900 mm / H2O

max. W x H x D (unit): 24 x 48 x 37 cm
max. W x H x D (package): 35 x 54 x 40 cm

Weight: 13 kg net/ 16 kg gross
Sound level: ≤ 59 dB (A)

Support Service:

Wassermann Dental-Maschinen GmbH
Rudorffweg 15 - 17
21031 Hamburg

Tel: +49 (0)40 730 926-0
www.wassermann-dental.com
sales@wassermann-dental.com